

100
YEARS
1919–2019

EVVA
access to security


Xesar 3.0 Service Pack 1

Xesar. Even easier to operate and more intuitive

Improved usability and new features



SIMPLE



Usability

Perform updates despite open maintenance tasks

You can now perform software updates despite of required maintenance tasks. However, this does not apply to upgrades from Xesar 2.2 to Xesar 3.x



SIMPLE

Type	Component type	Batt...
Automatik Tür		
Glastür		
Tür		

Usability

Help texts

Please note the question mark highlighted in yellow. Click once to view explanations of the individual input fields, lists or areas. Click the question mark once more to hide the help texts again.



SIMPLE

Filter by

Einbauort nicht aktuell Online Komponenten
unsichere Büros Zylinder leere Batterien

Filtered by

Online state
Not connected
Component type
Xesar online wall reader
Component status
Assigned

Usability

Filter presets

Filter settings that are needed repeatedly can be saved as presets in the user data. There is no limit to the number of presets that can be saved. They can be amended at any time. Your presets are shown in the filter field.

The screenshot shows the 'Automatic backup' section of the Xesar installation manager. It includes a 'Domain' field, a 'Timezone' dropdown set to 'Europe/Berlin', and a 'Backup path' field containing 'H:\Backup'. Under 'Automatic backup', there are checkboxes for 'On start', 'On stop', and 'Daily at' (which is checked). A time input field shows '02:00'. At the bottom, there are four circular buttons: 'Backup' (yellow), a refresh icon (blue), a cancel icon (red X), and a confirm icon (green checkmark).

Feature

Automatic backups when starting and stopping the Xesar system and during software updates

Automatic backups are now operated in the installation manager when the system is started and stopped. Backups can, however, also be performed manually or each day at a defined time. A backup is automatically performed before each update.

The screenshot shows the 'User group management' interface. It has a 'Name' field with 'BG Empfang Plus' and a 'Description' field with 'Benutzergruppe Empfang mit erweiterten Rechten'. Below these is an 'Authorisations' section with two expandable rows. The first row, 'General', has checkboxes for 'Select reading' (checked) and 'Select all' (checked). The second row, 'Persons', has checkboxes for 'Select reading' (checked) and 'Select all' (unchecked).

Feature

User group management

User group management can now be customised to meet your specific requirements. Individual, read-only or full editing rights can additionally be granted to these groups.



Increased usability

- **Customised scrolling area** – keep an overview with this usability feature: the heading rows remain while you scroll up and down in the list.
- **Mandatory fields marked with an asterisk** – mandatory fields can no longer be overlooked.
- **More characters for system designations** – we have extended the number of characters available for your system names, for example to include special characters.
- **Distinctive icons** – component and operating button symbols have been redesigned and are now easier to understand.
- **Adjustable column widths** – double-click on the column line to set the optimal width for the column heading.
- **Maintenance tasks without access authorisation** – optimized maintenance workflow: maintenance engineers no longer require access authorisation.
- **Extended period of validity of identification media** – the validity period can be set from 1 to 7,300 days (= max. 20 years).
- **Hide synchronisation tasks** – configuration tasks only are displayed.

Even more features

- **List exports** – as CSV or XLS files.
- **Identification media output log** – now including the name of the installation.
- **FW & SW version display** – the installed firmware and software is displayed under support.
- **User log for remote opening** – users who carry out remote opening are now logged.
- **Manual office mode with online wall reader** – even with the online wall reader, manual office mode can now be activated by holding up the identification media twice.
- **New filters** – new filter options are now available for installation locations, authorisation profiles and people.

